



## ELMER'S TIPS



### WHEN/HOW TO USE WOOD GLUE

**Interior Application:** Use interior wood glues for indoor gluing projects where protection from exterior exposure is required. The temperature of all components must be above 55° F. Surfaces must be clean, dry and free of dried glue, oil and any coating. Parts should fit tight. Apply glue liberally and evenly to the surfaces to be bonded. Join parts and clamp together. Clamping pressure should bring surfaces together and there should be some glue squeezed out from the joint. Remove excess wet glue with clean, dry cloth. Clamp for one hour or more. Let dry for 24 hours before handling.

**Exterior Application:** Exterior glues are designed to withstand outdoor weather elements such as temperature and moisture. The temperature of all components must be above 55° F. Surfaces must be clean, dry and free of dried glue, oil and any coating. Parts should fit tight. Apply glue liberally and evenly to the surfaces to be bonded. Join parts and clamp together. Clamping pressure should bring surfaces together and there should be some glue squeezed out from the joint. Remove excess wet glue with clean, dry cloth. Clamp for one hour or more. Let dry for 24 hours before handling.